

Care Tools



Washer Fluid



A clean microfibre cloth or paper towel

Optional



Dishsoap solution

1 drop dishsoap to 1 part water

or



Vinegar solution

1 part vinegar to 3 parts water



Damage to ExoShield film can be caused by

Power washing directly on film, heavy scrubbing, dirty squeegees at gas stations, harsh solvents, (toluene, acetone etc.) corrosive chemicals, polishing cleaners, water repelling products (RainX, Aquapell, etc.)

For more details, contact Alchemy Support at 1-844-326-3838

Film Care

Preventative Maintenance for users in high pollution environments such as construction sites, off roading conditions or during winter months is key to extending the life of your Exoshield.




Salt spray, bird droppings and insects should be cleaned off immediately to ensure optimal Exoshield condition.

Cleaning your ExoShield

Simply cleaning ExoShield when performing regular car maintenance can help lengthen its life. When cleaning, be sure to avoid scrubbing the film with any abrasive materials to prevent scratching.

- Manual Washing
- Touchless car washing stations (without brushes)
- Automatic/ Tunnel Car Wash Stations with Brushes



Always use sponges, paper towels or foam brushes that are clean to prevent scratches to the film

Wiper Care

Check for wear, deformation, cracking of rubber and residue under wipers every two weeks.

Any of the below may indicate the need for a new wiper



Streaking



Chattering




Smearing



Split rubber



Squeaking



Replace wipers every six months or at the first signs of wear

Cleaning your wipers

- Dampen microfibre cloth or paper towel in washer fluid or dish soap/ vinegar solution
- Wipe along the underside of the wiperblade until free from residue
- Wipe any remaining residue off of windshield before putting wipers back in place.